

DECLARE PROCESS SWAPPED-ECS CROSS-SECTION

(DF:XSEC)

IPl D: change in cross section

Action: Increments or decrements to process' swapped ECS cross section, getting or freeing space in the global swapped ECS pool. In the following cases, an R-return is initiated and the actual adjustment is returned in x6:

- a) If not enough swapped ECS is available from the pool on an increase request, as much as possible is obtained.
- b) If a call attempts to decrease the cross-section below the amount of ECS currently in use by the process, the cross section is set to the amount in use.